



IMPORTANT - READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ALL APPLICABLE LOCAL CODES, BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT, AND THE HAZARDS INVOLVED. PROPER GROUNDING IS REQUIRED FOR SAFETY.


NEW CONSTRUCTION PLASTER FRAME INSTALLATION (NC) - TRIM ONLY

- A- ENGAGE (4) HANGER BARS IN HOUSING SLOTS AVAILABLE AND CONNECT THEM TOGETHER.
- B- FASTEN HANGER BARS TO CEILING BRACE WITH #8 SCREWS (**NOT INCLUDED**). HOUSING MUST BE FLUSH WITH CEILING BRACE AND INSURE SMALL FOLDED TAB IS PLACED UNDER CEILING BRACE.
- C- MAKE THE CUT-OUT OPENING (**SEE DIMENSIONS BELOW**).



C


Model	Plaster Frame	Cut-out dimensions (A)	Ceiling thickness	Clearance
IESP096	BNIESP096RT-NC	Ø 3¾" (Ø 96mm)	0.04"-1" (1-25mm)	TBC
IESP153	BNIESP153RT-NC	Ø 6" (Ø 153mm)		
IESP212	BNIESP212RT-NC	Ø 8⅝" (Ø 212mm)		



DOWNLIGHT TRIM / ROUND MODEL: IESP096 / IESP153 / IESP212 - NC - 120 / 277V

- E- FASTEN HANGER BARS TO CEILING BRACE WITH #8 SCREWS (**NOT INCLUDED**). HOUSING MUST BE FLUSH WITH THE BOTTOM OF THE CEILING BRACES.
- F- INSTALL THE DRYWALL AND MAKE THE CUT-OUT OPENING (**SEE DIMENSIONS BELOW**).

E + F



FIXTURE INSTALLATION (TRIM ONLY)

- A- INSERT THE DRIVER BOX INTO THE CUT-OUT.
 - B- HOLD THE (2) CLIPS UPWARD AND INSERT FIXTURE INTO THE CUT-OUT.
- *FOR MAINTENANCE, PULL THE FIXTURE OUT OF THE CUT-OUT.**

A + B

