

DOWNLIGHT TRIM MODEL: ICRY3 / 6 / 9 T - RF - 120 / UNV


IMPORTANT - READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ALL APPLICABLE LOCAL CODES, BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT, AND THE HAZARDS INVOLVED. PROPER GROUNDING IS REQUIRED FOR SAFETY.

REMODEL INSTALLATION (RF) INTEGRAL DRIVER (120V / 120-277V) DIMMING 0-10V (D10) - TRIAC/ELV (LTE) - DALI (DA)

A- MAKE THE CUT-OUT OPENING (SEE DIMENSIONS BELOW).

A



Model	Cut-out dimensions	Clearance (H)
ICRY3	2 $\frac{9}{16}$ " x 7 $\frac{9}{16}$ " (64.5 x 185mm)	3 $\frac{3}{4}$ " (96mm)
ICRY6	2 $\frac{9}{16}$ " x 14 $\frac{5}{16}$ " (64.5 x 363mm)	
ICRY9	2 $\frac{9}{16}$ " x 21 $\frac{3}{8}$ " (64.5 x 543mm)	


CONNECTIONS

A- LOOSEN THE PHILLIPS COVER SCREW AND OPEN THE CONNECTION BOX COVER.


B- INSTALL BX CABLE (**NOT INCLUDED**) WITH 6" OF WIRE IN THE CONNECTION BOX.* **AN ADDITIONNAL BX CABLE MUST BE INSTALLED FOR DIMMING WIRING.**C- MAKE ALL NECESSARY CONNECTIONS (**SEE WIRING DIAGRAM BELOW**) USING TWIST CONNECTOR (**NOT INCLUDED**).

D- CLOSE THE CONNECTION BOX COVER AND FASTEN THE COVER SCREW.

A + B + C + D



WIRING DIAGRAM



FIXTURE INSTALLATION

A- INSERT THE LED DRIVER INSIDE THE CEILING CUT-OUT.

B- HOLD THE (2) CLIPS UPWARD AND INSERT FIXTURE INTO CUT-OUT.

A + B

